

920-216 braindumps

Nortel Other Nortel Certification

920-216: Multiservice Switch 7000/15000/20000 Operations and Maintenance

Practice Exam: 920-216 Exams

Exam Number/Code: 920-216

Exam Name: Multiservice Switch 7000/15000/20000 Operations and Maintenance

Questions and Answers: 113 Q&As

([Other Nortel Certification](#))



Exam : [920-216](#)

"Multiservice Switch 7000/15000/20000 Operations and Maintenance", also known as 920-216 exam, is a Nortel certification. With the complete collection of exam questions, Just4Study has assembled to take you through 113 Q&As to your 920-216 exam preparation. In the 920-216 exam resources, you will cover every field and category in Nortel Certification helping to ready you for your successful Nortel Certification.

The exam questions cover the latest real test and with all the correct answer. we promise the Q&A for Nortel Other Nortel Certification 920-216 (Multiservice Switch 7000/15000/20000 Operations and Maintenance) examination of original title complete coverage. 920-216 exam questions help you pass the exam.

Just4Study 920-216 Feature:

* High quality - High quality and valued for the 920-216 Exam: 100% Guarantee to Pass Your 920-216 exam and get your Other Nortel Certification certification.

* Authoritative - Authoritative braindumps with complete details about 920-216 exam.

* Cheaper - Our Just4Study products are cheaper than any other website. With our completed Other Nortel Certification resources, you will minimize your **Nortel Other Nortel Certification** cost and be ready to pass your 920-216 exam on Your First Try, 100% Money Back Guarantee included!

* Free - Try free Other Nortel Certification demo before you decide to buy it in <http://www.Just4Study.com>.

Just4Study Guarantee:

Just4Study provides the most competitive quality of all exams for the customers, we guarantee your success at the first attempt with only our Certification Question&Answers, if you do not pass the 920-216 exam at the first time, we will not only arrange FULL REFUND for you, but also provide you another exam of your claim, ABSOLUTELY FREE!

Free 920-216 Demo Download

Just4Study offers free demo for Other Nortel Certification 920-216 exam (Multiservice Switch 7000/15000/20000 Operations and Maintenance). You can check out the interface, question quality and usability of our practice exams before you decide to buy it. We are the only one site can offer demo for almost all products.

The Questions & Answers cover the latest real test and with all the correct answer.we promise the Q&A for **Nortel Other Nortel Certification 920-216** examination of original title complete coverage.920-216 Questions & Answers help you pass the exam. Otherwise,we will give you a full refund.

VUE/Prometric Code: 920-216

Exam Name: Multiservice Switch 7000/15000/20000 Operations and Maintenance(Other Nortel Certification)

Questions and Answers: 113 Q&A

[Nortel 920-216](#) Test belongs to one of the Other Nortel Certification certified test, if needs to obtain the Other Nortel Certification certificate, you also need to participate in other related test, the details you may visit the [Other Nortel Certification](#) certified topic, in there, you will see all related Other Nortel Certification certified subject of examination. Just4Study professional provide Other Nortel Certification 920-216 the newest Q&A, completely covers 920-216 test original topic. With our complete Other Nortel Certification resources, you will minimize your Other Nortel Certification cost and be ready to pass your 920-216 tests on Your First Try, 100% Money Back Guarantee included!

Just4Study Help You Pass Any IT Exam

[Just4Study.com](#) offers incredible career enhancing opportunities. We are a team of IT professionals that focus on providing our customers with the most up to date material for any IT certification exam. This material is so effective that we Guarantee you will pass the exam or your money back.

Exam : Nortel 920-216

Title : Multiservice Switch 7000/15000/20000 Operations and Maintenance

1. Which command is used to find the application versions that are compatible with base_CD01A?

- A. I sw av/base_CD01A
- B. d sw av/base_CD01A
- C. d sw compatibleListing
- D. d sw av/base_CD01A feat/*

Answer: B

2. A 4-port DS1 card is in slot 6 of a Multiservice Switch 7000. A trunking service runs on Port 3 of the DS1 card. What is the recommended instance value for this trunk?

- A. Trk/36
- B. Trk/43
- C. Trk/63
- D. Trk/DS16

Answer: C

3. Which command allows the output of alarms to the terminal to be disabled, while being logged into a Multiservice Switch 7000/15000/20000 node using telnet?

- A. set col/alarm sp spooling off
- B. set col/alarm sp spooling =off
- C. set NMIS Telnet session/ datastreams ala
- D. set NMIS Telnet session/ datastreams ~ala

Answer: D

4. Which verb is used to change an attribute value?

- A. set
- B. add
- C. load
- D. reset

Answer: A

5. A partial listing of the attributes of the provisioning component appears as follows:

```
committedFileName: startup.full.001
currentViewFileName: startup.full.003
lastUsedFileName: startup.full.005
editViewName: startup.full.005
```

Which view will be used if the switch resets or restarts?

- A. startup.full
- B. startup.full.001
- C. startup.full.003
- D. startup.full.005

Answer: B

6. Which verb can only be used in the provisioning mode?

- A. list
- B. lock
- C. help
- D. delete

Answer: D

7. Which attribute, under a DS3 port component, associates it with the Atmif service?

- A. lineInterface
- B. framerName
- C. interfaceName
- D. applicationFramerName

Answer: D

8. What is the maximum time allocated to confirm provisioning after activation?

- A. 5 minutes
- B. 10 minutes
- C. 20 minutes
- D. 30 minutes

Answer: C

9. Which two components can be provisioned directly under an LP component? (Choose two.)

- A. e0
- B. oc3
- C. ds3
- D. sonet

Answer: CD

10. Which selection is the instance range for a Logical Processor on a Multiservice Switch 7480?

- A. 0 to 4
- B. 0 to 15
- C. 1 to 15
- D. 0 to 16

Answer: B

11. Which type of view saves the provisioning of a single component and all of its subcomponents and associated provisionable attributes on a Multiservice Switch 7000/15000/20000?

- A. delta
- B. partial
- C. portable
- D. committed

Answer: B

12. Which provisioning view is active and running on the Multiservice Switch?

- A. edit view
- B. current view

- C. last used view
- D. committed view

Answer: B

13. Which two actions does the Multiservice Switch 7000/15000/20000 startup utility enable you to do? (Choose two.)

- A. Configure a spare Control Processor.
- B. Power-up the Multiservice Switch node.
- C. Reset node to Function Processor only software.
- D. Define the method used for Preside MDM connectivity.

Answer: AD

14. Which command is used to show all provisioning views stored on the Control Processor disk?

- A. display view/*
- B. list prov view/*
- C. list view/* prov
- D. display view/* prov

Answer: B

15. Which condition is true when performing a card test?

- A. The card being tested needs to be locked.
- B. The ports on the card being tested need to be locked.
- C. The target card's test component needs to be started first.
- D. A card can be both running a test and act as a target for another card being tested.

Answer: D

16. Which type of view has a base view on a Multiservice Switch 7000/15000/20000?

- A. delta
- B. partial
- C. portable
- D. committed

Answer: A

17. Which command is used to display the values of the "committedfilename", "currentviewfilename", and "editviewname" attributes?

- A. lock prov
- B. help prov
- C. list prov
- D. display prov

Answer: D

18. Which two provisioning conditions must apply to configure one-for-one sparing between two function processors on a Multiservice Switch 7480? (Choose two.)

- A. Both cards are provisioned as the same card type.
- B. Both cards are referenced under one logical processor.
- C. Both cards have individual logical processors that reference each other.
- D. An equal number of port components are provisioned under the Shelf Card components.

Answer: AB

19. The provisioning view startup.full.005 has been loaded into the edit view. Several components were added and attributes changed. The view was then checked, activated and confirmed.

What is the value of the "editviewname" attribute?

- A. none
- B. defined .005

C. startup.full.005

D. startup.full.006

Answer: A

20. Which provisioning view is loaded when a Multiservice Switch node resets?

A. edit view

B. current view

C. last Used view

D. committed view

Answer: D

[920-216 Braindumps](#)

Related 920-216 Exams

[922-109](#) *Communications Server 1000 RIs.6.0 BARS/NARS*

[922-111](#) *Communication Server 1000 to RIs.6.0 Upgrades for Technicia*

[922-081](#) *CallPilot RIs.5.0 Networking*

[920-457](#) *CallPilot RIs.4.0 Unified Messaging Exam*

[922-071](#) *BCM50 RIs.3.0 & BCM200/400 RIs.4.0 Config & Maintenance*

[920-569](#) *nncds-optera metro solutions*

[920-502](#) *nncss-optera metro 3000*

[922-104](#) *Communication Server 1000 RIs.6.0 Upgrades for Engineers*

[920-193](#) *ncss-business communications manager 50(bcm50)rls.1.0*

[920-110](#) *NNCSS SL-100 Maintenance Certification Exam*

[920-338](#) *BCM50 RIs.3.0 BCM200/400 RIs 4.0&BCM450 RIs. 1.0 Instal Con*

[920-806](#) *Nortel Advanced Data Networking Technology*

[920-220](#) *Nortel Converged Campus ERS Solution*

[920-805](#) *Nortel Data Networking Technology*

[922-030](#) *Carrier VoIP Engineering Fundamentals*

[922-094](#) *Communication Server 1000 RIs.5.0 Dialing Plan Design & IP*

[920-162](#) *callpilot 4.0 installation and maintenance exam*

[920-327](#) *MCS 5100 RIs.4.0 Commissioning & Administraion*

[920-123](#) *NCSS-BayStack/BPS Switching Exam*

[920-432](#) *Communication Server 1000 RIs.5.0-BCMRIs.4.0 Multi-site*

Other Nortel Exams

[920-327](#) [920-166](#) [920-170](#) [920-462](#) [920-122](#) [920-335](#) [920-352](#) [922-056](#)

[920-112](#) [922-059](#) [920-448](#) [920-161](#) [920-182](#) [922-097](#) [920-249](#) [920-171](#)

[920-160](#) [920-131](#) [920-537](#) [920-127](#)